

Dragon Skin^m

Addition Cure Silicone Rubber Compounds

PRODUCT OVERVIEW

Dragon Skin and Dragon Skin Q are high performance platinum cure silicone rubbers that can be mixed 1A:1B by weight or volume and cures at room temperature with no shrinkage to a Shore 10A. Cured Dragon Skin is very soft, very strong and very "stretchy". It will stretch many times its original size without tearing and will rebound to its original form without distortion.

Dragon Skin is suitable for many special effects applications, especially animatronics where repetitive motion is required. It is water white translucent and will accept pigments for creating color effects or for creating a paint that can be painted on to an existing Dragon Skin (or other) silicone surface. Because of the superior physical properties and softness of Dragon Skin, it is also used for orthopedic & cushioning applications. **Dragon Skin** has a pot life of 20 minutes and a demold time of 5 hours.

In A Hurry? Dragon Skin...Q (Q = Quick) has a pot life of 8 minutes and a demold time of 75 minutes.

TECHNICAL OVERVIEW

<u>Key Values:</u> ~Mixing Ratio: 1A to 1B by weight or volume ~Shore A Hardnesss: 10 ~Color: Translucent Clear						
	Properties	Viscosity	G/CC	Cu. In./Lb.	Tensile Strength	Mix Ratio
	Part A	-	-	-	=	100 pbw/pbv
	Part B	-	-	-	-	100 pbw/pbv
	Mixed	23,000 cps	1.07	25.8	475 psi	-
	Dragon Skin	Dragon Skin Q		~Elongation At Break 1000%		~100 % Modulus 22 psi
~ Pot Life*:	20 minutes	8 minutes		~Die C Tear Strength 102 pli		~Shrinkage Negligible
~Demold*:	5 hours	75 minutes		* at room temperature: $75^{\circ}F/23^{\circ}C$		

Preparation

Cure Inhibition – Addition cured silicone rubber may be inhibited by certain contaminants in or on the pattern to be molded (such as sulfur based clays, polyesters, certain wood surfaces, epoxies & urethane rubber) resulting in tackiness at the pattern interface or a total lack of cure throughout the mold. If compatibility between the rubber and the surface is a concern, a small-scale test is recommended. Apply a small amount of rubber onto a non-critical area of the pattern. Inhibition has occurred if the rubber is gummy or uncured after the recommended cure time has passed.

To prevent inhibition, a "barrier coat" of clear acrylic lacquer applied to the model surface is usually effective. Allow any sealer to thoroughly dry.

Applying A Release Agent? Although not usually necessary, a release agent will make demolding easier when casting into or over most surfaces. Ease Release 800tm does not contain silicone oil and is ideal for making molds with silicone rubber. Mann Ease Release tm products are available from Smooth-On or your Smooth-On distributor. If casting silicone into silicone, use Ease Release 800 tm only. ~IMPORTANT: To ensure thorough coverage, lightly brush the release agent with a soft brush over all surfaces of the model. Follow with a light mist coating and let the release agent dry for 30 minutes.

If there is any question about the effectiveness of a sealer/release agent combination, a small scale test should be made on an identical surface for trial. You can also contact Smooth-On for technical assistance.

Measuring & Mixing . . .

Materials should be stored and used in a warm environment (72° F / 23° C). Before you begin, pre-mix Part B (base) thoroughly. After dispensing required amounts of Parts A and B into mixing container (1A:1B by volume or weight), **mix thoroughly for 3 minutes** making sure that you **scrape the sides and bottom of the mixing container several times**. After mixing parts A and B, vacuum degassing is recommended to eliminate any entrapped air. Vacuum material for 2 -3 minutes (29 inches of mercury), making sure that you leave enough room in container for product volume expansion.

Pouring Curing Mold Performance

For best results, pour your mixture in a single spot at the lowest point of the containment field. Let the rubber seek its level up and over the model. A uniform flow will help minimize entrapped air. The liquid rubber should level off at least 1/2" (1.3 cm) over the highest point of the model surface.

Curing... Allow rubber to cure as prescribed at room temperature (75°F/23°C) before demolding. Full physical properties are attained after 24 hours cure at room temperature. Do not cure rubber where temperature is less than 65°F /18°C. Allow mold to cool to room temperature before using.

If Using As A Mold... When first cast, silicone rubber molds exhibit natural release characteristics. Depending on what is being cast into the mold, mold lubricity may be depleted over time and parts will begin to stick. No release agent is necessary when casting wax or gypsum. Applying a release agent such as Universal Mold Release or Ease Release 200 (available from Smooth-On) prior to casting polyurethane, polyester and epoxy resins is recommended to prevent mold degradation.

Safety First

The Material Safety Data Sheet (MSDS) for this or any Smooth-On product should be read prior to use and is available upon request from Smooth-On. All Smooth-On products are safe to use if directions are read and followed carefully.

Be careful. Use only with adequate ventilation. Contact with skin and eyes may cause irritation. Flush eyes with soap and water for 15 minutes and seek immediate medical attention. Remove from skin with waterless hand cleaner followed by soap and water.

Important: The information contained in this bulletin is considered accurate. However, no warranty is expressed or implied regarding the accuracy of the data, the results to be obtained from the use thereof, or that any such use will not infringe upon a patent. User shall determine the suitability of the product for the intended application and assume all risk and liability whatsoever in connection therewith.

Smooth-On offers a complete line of Liquid Rubber, Liquid Plastic and Release Agent products for hundreds of industrial and art related applications. Chances are there is a distributor in your area to offer local support.

Toll-free: (800) 762-0744 Fax: (610) 252-6200 Website: www.smooth-on.com